How to feed using
Nutrison Bolus Energy HP and Flocare Bolus Pouch Connector.


Make sure you have everything you need prepared on a clean surface



Nutrison Bolus Energy HP pouch



Flocare Bolus Pouch Connector



Water for flushing the feeding tube



Syringe for flushing the feeding tube

Before you start



Wash your hands



Check the expiry date of the connector and feed pouch, and that there is no damage to any of the packaging



Massage the pouch for 10 seconds to ensure no lumps are present



Flush your feeding tube as per your guidance from your managing HCP


Now connect the pouch to the connector and start administering




Ensure you close the clamp before connecting to the pouch




The connector has two different ends and A = connection for pouch, B = connection for feeding tube (ENFit end)



Loosen the cap from the pouch connection end (A) and keep it ready for use



Twist the cap to open the pouch - do not squeeze or tip once opened




Attach the connector securely onto the pouch



Ensure to twist until fully connected



Open the clamp then prime/fill the connector. Then close the clamp to avoid spillage.



Remove the cap from the connection for the feeding tube end (B)




Attach to feeding tube



Open the clamp



Slowly squeeze the pouch to administer the tube feed



Fold the pouch (repeat a couple of times) to ensure you empty


Once the pouch is empty



When the pouch is empty, disconnect the connector



Flush your feeding tube as per guidance from your managing HCP



Keep the connector attached to the empty pouch and place the cap back on the connector



Store the empty pouch and connector in a clean dry place. For example, a clean plastic container with lid or zip-lock bag



When it's time to use your next pouch, disconnect the connector from the empty pouch and follow the steps to connect to the new pouch



Discard the empty pouch in general household waste. Do not use the Flocare Bolus Pouch Connector for more than 24 hours. Discard in general household waste.

Important things to remember

General recommendations




Use a comfortable sitting semi-recumbent position. If unable, lay on one side




Before feeding, check the position of the feeding tube if instructed to do so by your managing HCP

Scan to view online sources


For the pouch



- ✓Store the unopened product in a cool and dry place with a temperature between 18–25°C
- ✓Avoid placing the product next to radiators or direct sunlight
- ✓This product has a shelf life of 9 months




Once opened, the pouch can be stored in the refrigerator for up to 12 hours, either with the cap or with the same connector still attached and closed




Recommended to only use in combination with the Flocare Bolus Pouch Connector

For the connector



Choking hazard; loose parts (ENPlus and ENFit caps; Nutrison Bolus pouch cap)



The Flocare Bolus Pouch Connector shall only be connected with ENFit enteral devices and Nutrison Bolus Energy HP



For enteral use only. Not for intravenous use. No modification to the devices allowed

For any clinical concerns please contact your managing Healthcare Professional

Nutrison Bolus Energy HP is a food for special medical purposes for the dietary management of disease-related malnutrition. It must be used under medical supervision.
The Flocare Bolus pouch connector is a medical device intended to connect to the Nutrison Bolus Energy HP pouch. Always follow the manufacturer's instruction for safe and effective use.

NUTRICIA
LIFE-TRANSFORMING NUTRITION